

DO NOT “DRY FIRE” THIS KIT. THE ONLY TIME THIS KIT SHOULD BE DRY FIRED IS WHEN IT IS REQUIRED FOR REMOVAL

DO NOT REMOVE ANY SCREWS

OILING INSTRUCTIONS

The conversion kits needs to be lightly lubricated to function properly. Shooting the kit dry will cause excessive friction and wear.

Figure 1. Place one drop of oil on each flat side of the barrel (3 sides) and rub it in with your finger. Figure 2. Place one drop of oil on each slide rail. Place one drop of oil on the firing pin. Place one drop of oil on the rib just in front of the firing pin.

Lightly Oil These Three Surfaces



Figure 1

Do Not Remove This Screw

Lightly Oil Each Slide Rail, Firing Pin and Rib



Figure 2

DO NOT touch the side of the slide with your thumb, or any portion of your hand while shooting

